

# Belt Conveyor

BF40E IK - 1200 - 1000 - 38 - RV4 T L F 5 B - 1 1 0 0 0 0

**Size**

BF40  
BF80

**Type**

E = End  
M = Middle

**Knife edge**

IK = In Feed  
OK = Out Feed  
DK = Double / Both

**Width**

**Length**

c/c roller

**Speed**

**Motor side**

R = Right  
L = Left

**Motor orientation**

H1  
H2  
H3  
H4  
V1  
V2  
V3  
V4

**Belt type**

See website or contact us for further information.

**Conveyor guides left**

0 = No guides  
1 = Bent side  
2 = Side support alu  
3 = Adj. side support

**Conveyor guides right**

0 = No guides  
1 = Bent side  
2 = Side support alu  
3 = Adj. side support

**Belt profiles**

0 = No option  
1 = Quadratic profiles  
2 = Thin profiles  
3 = Wide angled profiles  
4 = Side walls

**Tracking guides**

0 = None  
1 = K6 (6x4x4)  
2 = Kn8 (8x5x5)  
3 = Kn10 (10x6x6)

**Stand**

0 = No  
1 = Yes

**Motor**

BF40:  
0 = No motor  
1 = MS63A-4  
2 = MS63B-4  
3 = MS63C-4  
4 = ML63B-4

BF80:  
0 = No motor  
5 = MS71A-4  
6 = MS71B-4  
7 = MS80A-4  
8 = MS63B-4 B5

# Stand

BS 40 - XXXX - XXXX HXXX - X - XXXX 0 0 02

**Profiles**

- 40 = 40x40 Semi Profiles
- 80 = 40x80 Semi Profiles

**Width**

**Length**

**Height**

**No. of sections**

**Profile length (l1)**

**Attachments**

- 1 = Corner Brackets
- 2 = T-Plate

**Foot plate**

- 0 = Without foot plate
- 1 = With foot plate

**Floor attachments**

- 01 = Swivel castor with total lock and bolt hole
- 02 = Swivel castor with bolt hole
- 03 = L-Based Foot
- 04 = Angle Foot AI, adjustable
- 05 = Adjustable Foot Ø 39 M8 / L 65
- 06 = Adjustable Foot Ø 39 M10 / L 65
- 07 = Adjustable Foot Ø 79 M8 PSD / L 71
- 08 = Adjustable Foot Ø 79 M10 PSD / L 71
- 09 = Adjustable Foot Ø 79 M12 PSD / L 71
- 10 = Adjustable Foot Ø 79 M16 SVD / L 161
- 11 = Adjustable Foot Ø 79 M10 SVDB / L 71
- 12 = Adjustable Foot Ø 79 M12 SVDB / L 151
- 13 = Adjustable Foot Ø 79 M16 SVDB / L 161

**Note:**

All our conveyors are skillfully adjusted and tested on our factory floor before delivery. After delivery and placement however we cannot guarantee perfect running and strongly recommend final adjustments to be made. Please see the documentation provided with the conveyor for more information on how best to do this. Note that most tracking problems occur from uneven assembly of conveyor bases or flooring and that belt tension should be maintained when adjustments made. Motors are not individually tested and not assembled to the unit during transport.